

INTERCOM MOUNTING

ON FRONT FENCE



Customers:
It is your responsibility to run the conduit from the house right through to the Connection point of your intercom. Sentinel Alarms will NOT DO this for you.
Only book the callout to connect the Gate Station when the conduit has been COMPLETED.

The conduit must have a pull through string or cable over the full length of the conduit.
Note: All intercoms mounted on fences require a weatherproof cover to prevent water damage.

